The Installation of Cessna Sea



STEP — Pictures 1.2.3.4.5 Connect the two floats using the rod A and screws as the picture.

STEP 二

Pictures 6.7.8.9

Taking out the rod B, please pay attention the two terminals are not same, then install the bigger camber side to the front of float as the picture.

STEP \equiv

Pictures 10.11.12.13

Taking out the rod C, please pay attention the two terminals are not same, then install it to the end of the float as the picture.

STEP 四

Pictures 14.15.16.17

Taking out the rod D1 & D2, install them to the end of float respectively as the picture.

STEP 五 Pictures 18

Upward the bottom of the Cessna 182 on the support and then put the finished float on the setting parts

STEP 六

Pictures 19.20.21 Fix the float to the position of floating by tighting screw to avoid loose

STEP 七

Pictures 22

Insert the push rod of the water rudder to the adjustments on the horn and then tight by screw

STEP 八

Pictures 23

Fix the push-rod for water rudder to the D1 & D2 rod by Nylon tape, Fixing position should be around 60mm far from the bottom of "D Rod"

STEP 九

Pictures 24. 25 Secure the Nylon knot by the fast glue to avoid slide of push rod for rod

STEP + Pictures 26.27.28.29

Connect the two floatings with the wing by "V" type thread as the pictures show and secured it to avoid the floating support distortion

STEP +-Pictures 30.31 The receiver must be envelopped by the waterproof bag and seal it to secure it cant be wet













































